




# Nokia E71x Camera Flash Replacement

This guide will help you install a new flash "bulb" to your phone.

Written By: Will Goldby



## INTRODUCTION

In this guide you will be taking apart most of the phone in order to access the flash and replace it.

---



### TOOLS:


- [T4 Torx Screwdriver](#) (1)
-

## Step 1 — Motherboard



- Remove battery


## Step 2



- Using Torx number 4 unscrew the four 0.5mm screws.






## Step 3




- Push in four clips to detach the body.


## Step 4



- Separate the body into two pieces.


 Be careful not to damage the screen or body. Some force will be needed to separate the body.

## Step 5



- Remove the bottom piece that is clipped on.
- Some force will need to be exerted to remove the clip.



## Step 6



- Using Torx number 4 unscrew the two 0.7 mm screws at the top of the device.




## Step 7



- Once screws are removed detach back of phone from the motherboard.


⚠ This will require some force and maneuvering. Be careful not to break phone back or motherboard.

## Step 8



- Replace motherboard, ensure that replacement has the same serial number.

## Step 9 — Camera Flash



- Camera is located on back of camera body.
- ⓘ To remove flash turn body over and gently tap on the case. The flash should fall out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-21 10:32:07 PM.